

# ⚠️ ご使用上の注意

## 永く安全にお使い頂くため、最初に必ずご一読ください

---

### 初めてご使用になる前に

- 台所用の中性洗剤をつけた柔らかいスポンジで洗淨した後、よく乾いた布などでお拭き下さい。

### ご使用中の禁止事項

- 本製品は食器です。本来の目的以外での使用はお止めください。
- 電子レンジ、オープンレンジ等の電気調理器具、食洗機・乾燥機は使用しないでください。
- 火にかけたり、熱いものを入れてのご使用は絶対にお止め下さい。やけどの危険がございます。
- 飲食物の保存には使用しないでください。  
製品・飲食物の傷みの原因となりますので、中身が入ったまま放置するのはお止め下さい。
- 漂白剤やシンナーは使用しないでください。
- 冷凍庫には保管しないで下さい。
- 強い衝撃は、変形や破損の原因となります。  
安全のため、破損が生じた場合は直ちにご使用をお止めください。

### 製品の変質について

- 表面に緑青（ろくしょう）と呼ばれる青サビが発生する場合がございます。  
人体に無害ですのでご使用に差支えございません。
- 醤油、酢、レモンなどの強い酸に触れると、変色・色落ちの原因となります。
- ご使用の間に変色やメッキのはがれが発生する場合がございます。  
そのままお使い頂けますので、経年変化をお楽しみ下さい。

### お手入れについて

- 毎回の洗淨後には、すぐに水気を拭き取ることで変色やサビを防げます。
- 本製品は傷付きやすい素材でできています。積み重ねての保管、研磨剤・たわし等のご使用はお控え下さい。
- 長期保管される際はぬるま湯で仕上げ洗いをして水気を十分拭き、新聞紙等で包んだ後  
湿気の少ない場所に保管してください。

### お問い合わせについて

- 商品等についてご不明な点は、ご気軽にお問い合わせ下さい。

株式会社 西井製作所

〒736-0055 広島県安芸郡海田町南明神町 1 番 17 号

TEL: 082-821-0241 (代) Fax: 082-821-0241

U R L: <http://www.hiroshima-nishii.co.jp>

メール: [nishii@hiroshima-nishii.co.jp](mailto:nishii@hiroshima-nishii.co.jp)

受 付: 8:20 ~ 17:30 (土日・祝日を除く)

<b>製品</b> / 食器 <b>素材</b> / 銅 (模様付き製品の模様部分: クロムメッキ) <b>表面加工</b> / 内面: 錫メッキ    外面: 硫化仕上げ (クリアコーティング)
---

# Instructions for use

**For your continued enjoyment of our products, please read the instructions before using.**

## Before the first time use and after every time use

- Wash this product with a sponge and dish detergent, and dry it with a soft dry cloth.

## Prohibitions during use

- This product is tableware. Use only for intended purpose.
- Do NOT use this product in a microwave oven or a toaster oven, or wash in a dish washer.
- Do NOT heat this product over a fire or a stove, or use it with hot liquids or food. There is a risk of burns.
- Do NOT use this product for food or liquid storage or leave it with food or liquid in it.  
There is a risk for both this product and liquid/food getting damaged.
- Do NOT use dish bleach or thinner for cleaning this product.
- Do NOT put in the freezer this product.
- Do NOT apply excessive force to avoid breakage or deformation of this product.

For safety reasons, discontinue use in case it is broken or deformed.

## Alteration of this product

- Copper rust or green rust may occur on the surface of this product.  
This rust is harmless to humans, so this product can be used continuously.
- Handle this product carefully when using strong acid like soy-sauce, vinegar, or lemon, which may cause it to get discolored or color-faded.
- Tin may come off and the color may vary while using this product.  
It can be used as is and enjoyed as it varies over time.

## Cares

- Staining can be prevented by wiping it dry immediately after washing.
- This product is made of a delicate and sensitive material.  
Do NOT stack this product vertically with others, or use scrub brushes or a gritty cleanser.
- Before long-term storage, wash this product with warm water and dry it well, then store it in a dry place after covering it with newspapers.

## Contact Us

- Please feel free to contact us with any questions you may have about our products.

Nishii Mfg. Co., Ltd

1-17 Minami myojin-machi Kaita-cho, Aki-gun Hiroshima 736-0055 Japan

Phone: 81-82-821-0241 Fax: 81-82-821-0241

URL: <http://www.hiroshima-nishii.co.jp> E-mail: [nishii@hiroshima-nishii.co.jp](mailto:nishii@hiroshima-nishii.co.jp)

Open: From 8:20 to 17:30 (Closed on weekends and National holidays)

<b>Product</b> / tableware <b>Material</b> / Copper (Patterned area: Chrome Plating) <b>Surface Treatment</b> / <i>Inside</i> : Tin Plating <i>Outside</i> : Sulfide Finish (Clear Coating)
--